



Model Number: R652L





Auto Programm and Description

Refresh	Master mode, full body massage, the intensity of roller and airbag massage is stronger.
Relax	Relaxing mode, full body massage, medium intensity for roller and airbag massage.
Stretch	Press this button to primarily stretch your body with movement and air pressure
Neck&Shoulder	Partial massage, focus on improving neck pain and shoulder muscle strain, the roller is focusing more on the neck and shoulder massage.
Waist&Back	Partial massage, focus on the waist and back massage to improve back pain, the roller is focusing more on the waist back massage.
Dream	Full body massage, light intensity for roller.

1. Turn on the power button on the remote controller to operate the massage chair
2. After press the power button, it will enter the auto mode programm. Choose the different auto mode from the remote controller.
3. To adjust the details as users' requirement (strength, air pressure, angles, time, bluetooth speaker etc)
4. Enjoy the massage

Outer Structure





Controller Intruccion

Function	Button	Instruction
Power		Connect the power supply, press this button to start the massage chair. It will start the body diction and then start the default automatic program for massage.
Menu		Press this button to enter the UI interface.
Stop		Press this button to pause the massage function. Press again to resume the original massage function.
Auto		Press this button to switch between multiple automatic program functions. The specific display is subject to the actual product.
4-Way Direction & OK Button		Under the menu UI interface, press the arrow keys to select the corresponding function, press the OK button to confirm the function.
Airbag		Press this button to the airbag menu. Use the 4-way button to adjust and select your desired massage area and intensity.
Heat		Press this button to turn ON/OFF the heating function.
Zero-G		Press the button to recline chair to Zero-G angle. The screen shows the Zero-G icon. If the icon doesn't appear on the screen, the Zero-G function is turned off.
Up/Down		Press the Up/Down button to manually adjust the appropriate shoulder position.
Leg Up/Down		Press the Leg Up/ Down button to adjust the leg angle.
Back Up/ Down		Press the Backrest Up/ Down button to adjust the backrest angle.

Model Number	R652L		
Type	Massage Chair	Time	10 min/20 min/30 min
Specification	Power	160W	Volt 100-240V/50-60Hz
Carton size	1205*760*1150MM	N.W/G.W	81KGS/97KGS
Materials	Metal, Plastic,ABS,Synthetic Leather		

MARKING PLATE

